

4.0

MEGAPIXEL

20x30
50x75cm
MAXIMUM
PRINT SIZE3.0X OPTICAL
ZOOM
3.3X ADV DIG ZOOMINDOOR/OUTDOOR
ROTATING DISPLAY256MB
INTERNAL
MEMORYVGA
VIDEO/AUDIO
WITH ZOOMshare
SHARE
BUTTON

FAVORITES

MULTI SCENE MODES

AUTO PICTURE
ROTATIONMULTI-ZONE
AUTO FOCUSMATRIX
METERINGCOMPATIBLE WITH
SERIES 3 DOCKS

Kodak EasyShare-one

Standard Features

CCD resolution – 4.23 megapixel (2408x1758 pixels)

Image resolution – 4.0 megapixel (2304x1728 pixels)

Image quality

4.0MP – best (print, enlargement)

3.5MP – best (optimized ratio for 4" x 6" prints, 3:2)

2.1MP – better (small prints)

1.1MP – good (e-mail)

Lens

3.0X optical zoom, 6.0-18.0 mm (35 mm equivalent: 36-108 mm)

3.3X advanced digital zoom

10X total zoom

Auto-focus – TTL auto-focus with selectable modes: multi-zone, center-spot

Focus range

wide: 60 cm (24 in.) to infinity

tele: 60 cm (24 in.) to infinity

LCD – 3.0 in. (7.6 cm) high-resolution (230K pixel) indoor/outdoor display with polarizer and touchscreen with stylus

Aperture – f/2.9 or f/4.7 (wide), f/4.9 or f/8.1 (tele)

Shutter speed – 4-1/1400 sec.

ISO equivalent – automatic, (80-160); manual (80, 100, 200, 400)

White balance – auto, daylight, tungsten, fluorescent

Built-in flash – auto, red-eye, fill, off

Flash range

wide – 0.6-3.1 m (2-10.2 ft.)

tele – 0.6-2.1 m (2-6.9 ft.)

Self-timer – user selectable, 2-30 seconds

Creative Performance Features

Scene modes – auto, portrait, close-up, self-portrait, museum/manner, night portrait, sport, children, snow, beach, party, landscape, flower, backlight, night landscape and fireworks

Close-up mode

wide – 10-70 cm (4-27 in.)

tele – 43-70 cm (17-27 in.)

Burst mode – 2 fps, up to 6 images

Color modes – high color, standard color, low color, black and white, sepia

Exposure metering – automatic: TTL-AE; selectable: multi-pattern, center-weighted, center spot

Exposure compensation – +/-2.0 EV in 0.3 EV step increments

Exposure control – programmed AE

Click to capture – <0.5 sec (wide)

Shot to shot – <1.5 sec

Video mode – continuous MPEG-4 video with audio capture, playback on camera

Video resolution – VGA (640x480 pixels) at 30 fps

Video length – up to 80 min. limited by capacity of external memory card

Zoom during video – 3x optical zoom

Selectable sound themes

Effortless Operation

Auto picture rotation

Dedicated buttons – power, delete, menu, Share, flash setting, back, info, capture/review mode

Review modes – slide show, protect, share/print, multi-up, image storage, copy, picture info, favorites, view by date, view by album

On camera assistant

Video out – NTSC, PAL (user-selectable)

Software – Kodak EasyShare software

Dock compatibility – Kodak EasyShare printer dock series 3, Kodak EasyShare camera dock series 3

Kodak EasyShare printer dock plus**, Image Link print system compatible

Additional Features

Storage – 256 MB internal memory, SD/MMC card expansion slot

Wireless – SDIO Wi-Fi 802.11b

Power options – Kodak rechargeable Lithium-Ion battery KLIC-5000, DC-in jack on side of camera for 5V adapter, via the Kodak EasyShare dock series 3 terminals

Image recording format – Still: JPEG/EXIF v2.21, Video: Quicktime MOV

Interface – USB compliant, Kodak EasyShare series 3 docks, audio/video connectors

Lens protection – built-in lens barrier

Tripod mount – 1/4 in. standard

Weight – without batteries: 225 g (7.9 oz.)

Dimensions – WxHxD: 103x63x26 mm (4.1x2.5x1.0 in.)

Warranty – one year

Minimum System Requirements

Windows 98, 98SE, ME, 2000 SP1, or XP OS

233 MHz processor or greater

(300 MHz recommended for XP)

64MB RAM (128MB for XP)

Internet Explorer 5.01 or higher

4MP ZOOM
DIGITAL
CAMERA

PowerMac or PowerBook G3, G4, G5; iMac;

eMac; or iBook

Macintosh OS X 10.2.3-10.2.8, 10.3 or greater

128 MB RAM for OS X (64 MB RAM

for OS 8.6/9.x)

Safari 1.0 or higher

Minimum hardware requirements

200MB hard drive disk space available

CD-ROM drive

Available USB port

Package Contents

Kodak EasyShare-one S143 zoom digital camera with built-in lens cover

Wrist strap

Kodak EasyShare Li-Ion rechargeable battery and charger

Stylus

Audio/video cable

USB cable

Kodak EasyShare software

Getting Started kit

Custom camera insert for optional Kodak EasyShare printer dock and camera dock series 3

Ordering Information

Kodak EasyShare-One S143 zoom digital camera

xxx xxxx – English/French/Spanish

Recommended Accessories

Kodak EasyShare printer dock series 3 – xxx xxxx

Kodak EasyShare printer dock plus – xxx xxxx

Kodak color cartridge and photo paper kit – xxx xxxx

Kodak EasyShare camera dock series 3 – xxx xxxx

Kodak Wi-Fi card – xxx xxxx

Kodak stylus (3-pack) – xxx xxxx

Kodak EasyShare Picture Viewer – xxx xxxx

Kodak 8-in-1 card reader – xxx xxxx

Kodak SD memory cards – 512 MB – xxx xxxx

Kodak EasyShare Li-Ion rechargeable battery (1050 mAh) – xxx xxxx

Kodak EasyShare Li-Ion rapid battery charger kit – xxx xxxx

For more information on the Kodak EasyShare-one 4.0 zoom digital camera, visit www.kodak.com/go/easyshare



©Eastman Kodak Company, 2005. Kodak, EasyShare, the Share button, EasyShare-one, Image Link, and the Image Link print system logo are trademarks of Eastman Kodak Company. Schneider-Kreuznach and C-Variogon are trademarks of Jos. Schneider Optische Werke GmbH used under license by Eastman Kodak Company. Product specifications subject to change without prior notice. Simulated LCD display image. IC-xxx CAT No. xxx

*Optional Kodak Wi-Fi card sold separately.

**Kodak EasyShare-one digital camera is also compatible with the Kodak EasyShare printer dock and camera dock series 3, as well as the Kodak EasyShare printer dock 6000 and camera dock 6000 when used with Kodak adapter kit D-22.

Kodak